

- 1. Norris to determine bore path, distances, junction box and transformer locations.
- 2. Norris will cut duct off as needed to install junction boxes and transformers.
- 3. If meter location is farther than 5' from transformer location, duct must be bored in place like duct to transformer.
- 4. Also see sheets 1 and 2 of Single Phase, 120/240v, 200 AMP ONLY, Underground Meter Installations.
- 5. Contractor to flag bore when installed.